Deep Learning-based Leak Detection for Smart Water Metering with Consumption Forecasting



Problem Identified

DENR airs concern over water leaks in houses, buildings


Bella Cariaso - The Philippine Star (1) May 9, 2024 | 12:00am



Almost 1.7 cubic meters per second of water lost due to pipe leaks — Manila Water

By GISELLE OMBAY, GMA Integrated News

Published April 3, 2023 10:15am Updated April 3, 2023 11:36am



Problem Statement

Water pipeline leaks cause significant losses in urban systems, yet traditional detection methods are often manual, inaccurate, and inefficient. This project proposes a deep learning-based approach that combines automated leak detection and water consumption forecasting using images and numerical data. Our goal is to enhance detection accuracy, and support smarter, real-time water management.



Dataset Chosed

OBJECT DETECTION

Pipeline Leak Prediction (Roboflow)
https://universe.roboflow.com/gas-leak/pipeline-leak-prediction

Contents:

images of pipelines that has leaks and no leaks

FOR LSTM

A synthetic dataset made of water consumption consisting 10 thousands of sets of it.

Methodology


Dual-Model Approach: Object Detection and Time Series Analysis



Leak Detection Model









RetinaNet

Consumption Forecasting Model










Dataset prep for Yolov11 Model


Pipeline Leak Prediction Dataset (from Roboflow)							
SET	Total Images	Leak	No leak	Water	Crack		
Training	2739	1099	623	847	170		
Validation	488	193	91	168	36		
Total	3227	1292	714	1015	206		



Data Augmentation already applied



85% training 15% validation



Preprocessed via Roboflow

Training of Objection Detection Models




- enhance feature extraction + object localization
- high inference speed and improved detection precision



• fast training on single or multiple GPU servers and includes high-quality implementations of numerous advanced models like Mask R-CNN, Cascade R-CNN, and Panoptic FPN.

RetinaNet

- Addresses Class Imbalance in One-Stage Detectors
- Balances Speed and Accuracy



Deployment of Leak Detection Model in Streamlit







RetinaNet


Results and Discussion




Leak Detection Model Performance Evaluation















Performance Metrics of YOLOv11 model



peaking at 0.81 around a confidence threshold of ~0.527.
 This shows good indication that the yolo model performs reliably when it is reasonably confident



- Precision and recall trade-offs are well balanced for most classes except "no leak."
- An mAP@0.5 of .860 indicates good object localization and classification confidence, particularly for leak-related targets.


Performance Metrics of YOLOv11 model

	YOLOv11	Model Performance E	valuation	90
Class	Images	Instances	R	mAP50
all	502	492	0.767	0.859
crack	36	36	0.832	0.946
leak	193	199	0.899	0.942
no leak	91	92	0.554	0.663
water	168	169	0.783	0.885

1st test of Detectron2 model

```
cfg = get_cfg()
cfg.merge_from_file(model_zoo.get_config_file("COCO-Detection/faster_rcnn_R_50_FPN_3x.yaml"))
cfg.DATASETS.TRAIN = ("leak_dataset_train",)
cfg.DATASETS.TEST = ("leak_dataset_val",)
cfg.DATALOADER.NUM_WORKERS = 2
cfg.MODEL.WEIGHTS = model_zoo.get_checkpoint_url("COCO-Detection/faster_rcnn_R_50_FPN_3x.yaml")
cfg.SOLVER.IMS_PER_BATCH = 2
cfg.SOLVER.BASE_LR = 0.00125
cfg.SOLVER.BASE_LR = 0.00125
cfg.SOLVER.MAX_ITER = 2000
cfg.MODEL.ROI_HEADS.BATCH_SIZE_PER_IMAGE = 128
```







1st test of Detectron2 model








1st test of Detectron2

model

```
Average Precision (AP) @[ IoU=0.50:0.95
                                                        maxDets=100 ] = 0.344
                                          area=
Average Precision (AP) @[ IoU=0.50
                                          area=
                                                  all | maxDets=100 ] = 0.497
Average Precision (AP) @[ IoU=0.75
                                          area=
                                                  all | maxDets=100 ] = 0.370
Average Precision (AP) @[ IoU=0.50:0.95
                                          area= small |
                                                        maxDets=100 ] = -1.000
Average Precision (AP) @[ IoU=0.50:0.95 | area=medium |
                                                        maxDets=100 ] = 0.212
Average Precision (AP) @[ IoU=0.50:0.95 |
                                          area= large |
                                                        maxDets=100 ] = 0.348
Average Recall
                   (AR) @[ IoU=0.50:0.95 | area=
                                                  all I
                                                       maxDets= 1 ] = 0.534
Average Recall
                   (AR) @[ IoU=0.50:0.95 |
                                          area=
                                                        maxDets= 10 ] = 0.622
Average Recall
                   (AR) @[ IoU=0.50:0.95
                                          area=
                                                  all I
                                                        maxDets=100 ] = 0.631
                   (AR) @[ IOU=0.50:0.95
Average Recall
                                          area= small |
                                                        maxDets=100 ] = -1.000
Average Recall
                   (AR) @[ IoU=0.50:0.95 |
                                          area=medium | maxDets=100 ] = 0.268
                   (AR) @[ IoU=0.50:0.95 | area= large | maxDets=100 ] = 0.654
Average Recall
[05/22 16:31:55 d2.evaluation.coco_evaluation]: Evaluation results for bbox:
                    AP75
                                    APm
|:----:|:----:|:----:|
 34.432 | 49.703 | 36.961 | nan | 21.236 | 34.785 |
[05/22 16:31:55 d2.evaluation.coco evaluation]: Some metrics cannot be computed and is shown as NaN.
[05/22 16:31:55 d2.evaluation.coco_evaluation]: Per-category bbox AP:
                                             category
 category
                       category
:-----
 leakage
                                   42.730 | leak
                                                        48.876
                       crack
                                   35.301
 no leak
             10.821 | water
OrderedDict([('bbox',
             {'AP': 34.43207423228552,
              'AP50': 49.70307085589206,
              'AP75': 36.961087166617936,
              'APs': nan,
              'APm': 21.23628686307657,
              'APl': 34.78472621458232,
              'AP-leakage': nan,
              'AP-crack': 42.73049901827959,
              'AP-leak': 48.876384873901344,
              'AP-no leak': 10.820891749531853,
              'AP-water': 35.3005212874293})])
```

2nd test of Detectron2 model



```
cfg = get_cfg()
cfg.merge_from_file(model_zoo.get_config_file("COCO-Detection/faster_rcnn_R_50_FPN_3x.yaml"))
cfg.DATASETS.TRAIN = ("leak_dataset_train",)
cfg.DATASETS.TEST = ("leak_dataset_val",)
cfg.DATALOADER.NUM_WORKERS = 2
cfg.MODEL.WEIGHTS = model_zoo.get_checkpoint_url("COCO-Detection/faster_rcnn_R_50_FPN_3x.yaml")
cfg.SOLVER.IMS_PER_BATCH = 4
cfg.SOLVER.BASE_LR = 0.00125
cfg.SOLVER.MAX ITER = 5000
cfg.SOLVER.STEPS = []
cfg.TEST.EVAL_PERIOD = 500
cfg.SOLVER.OPTIMIZER = "ADAMW"
cfg.SOLVER.WEIGHT_DECAY = 0.0005
cfg.SOLVER.AMSGRAD = True
cfg.MODEL.ROI_HEADS.BATCH_SIZE_PER_IMAGE = 32
cfg.MODEL.ROI_HEADS.SCORE_THRESH_TEST = 0.5
```





2nd test of Dectectron 2 model



2nd test of Detectron2 model

```
[05/22 17:53:23 d2.evaluation.fast eval api]: COCOeval opt.accumulate() finished in 0.02 seconds.
Average Precision (AP) @[ IoU=0.50:0.95 |
                                        area=
                                               all | maxDets=100 ] = 0.571
Average Precision
                                                     maxDets=100 ] = 0.742
                  (AP) @[ IOU=0.50
                                        area=
                                               all I
Average Precision
                                                     maxDets=100 ] = 0.608
                  (AP) @[ IOU=0.75
                                        area=
Average Precision
                                                     maxDets=100 ] = -1.000
                  (AP) @[ IoU=0.50:0.95 |
                                        area= small
Average Precision (AP) @[ IoU=0.50:0.95 |
                                        area=medium |
                                                     maxDets=100 ] = 0.375
Average Precision (AP) @[ IoU=0.50:0.95 |
                                                     maxDets=100 ] = 0.592
                                        area= large
                                               all | maxDets= 1 ] = 0.651
Average Recall
                  (AR) @[ IoU=0.50:0.95 |
                                        area=
                                               all | maxDets= 10 ] = 0.700
Average Recall
                 (AR) @[ IoU=0.50:0.95 |
                                        area=
                                               all | maxDets=100 ] = 0.700
Average Recall
                  (AR) @[ IoU=0.50:0.95 |
                                        area=
Average Recall
                                        area = small | maxDets = 100 ] = -1.000
                  (AR) @[ IOU=0.50:0.95
Average Recall
                  (AR) @[ IOU=0.50:0.95
                                        area=medium | maxDets=100 ] = 0.535
Average Recall
                  (AR) @[ IoU=0.50:0.95 | area= large | maxDets=100 ] = 0.716
[05/22 17:53:23 d2.evaluation.coco evaluation]: Evaluation results for bbox:
          AP50
                   AP75 | APS |
                                  APm
                                           AP1
|:----:|:----:|:----:|
| 57.051 | 74.164 | 60.793 | nan | 37.521 | 59.171 |
[05/22 17:53:23 d2.evaluation.coco_evaluation]: Some metrics cannot be computed and is shown as NaN.
[05/22 17:53:23 d2.evaluation.coco evaluation]: Per-category bbox AP:
                     category
 category
                                          category
leakage
                     crack
                                 63.591 | leak
                                                      67.730
             nan
 no leak
            | 38.043 | water
                                  58.841
```

1st test on Retinanet Model

```
# Load configuration from a RetinaNet config file
cfg.merge_from_file(model_zoo.get_config_file("COCO-Detection/retinanet_R_50_FPN_3x.yaml"))


cfg.DATASETS.TRAIN = ("leak_dataset_train",)
cfg.DATASETS.TEST = ("leak_dataset_val",)
cfg.DATALOADER.NUM_WORKERS = 2

# Load weights from a RetinaNet checkpoint
cfg.MODEL.WEIGHTS = model_zoo.get_checkpoint_url("COCO-Detection/retinanet_R_50_FPN_3x.yaml")

cfg.SOLVER.IMS_PER_BATCH = 2
cfg.SOLVER.BASE_LR = 0.00125
cfg.SOLVER.MAX_ITER = 2000
num_classes_from_dataset = len(leak_metadata.thing_classes)
cfg.MODEL.RETINANET.NUM_CLASSES = num_classes_from_dataset
```








1st test on Retinanet Model

```
Average Precision (AP) @[ IoU=0.50:0.95
                                                       maxDets=100 ] = 0.411
                                         area=
Average Precision
                  (AP) @[ IoU=0.50
                                                       maxDets=100 ] = 0.580
                                          area=
Average Precision (AP) @[ IoU=0.75
                                                       maxDets=100 ] = 0.437
                                         area=
                                                 all I
Average Precision (AP) @[ IoU=0.50:0.95 | area= small | maxDets=100 ] = -1.000
Average Precision (AP) @[ IoU=0.50:0.95 | area=medium | maxDets=100 ] = 0.253
Average Precision (AP) @[ IoU=0.50:0.95 | area= large | maxDets=100 ] = 0.416
Average Recall
                   (AR) @[ IoU=0.50:0.95 |
                                                 all | maxDets= 1 ] = 0.520
                                         area=
Average Recall
                                                       maxDets= 10 ] = 0.622
                   (AR) @[ IOU=0.50:0.95
                                                 all
                                         area=
Average Recall
                   (AR) @[ IOU=0.50:0.95 |
                                         area=
                                                 all | maxDets=100 ] = 0.633
Average Recall
                   (AR) @[ IoU=0.50:0.95 | area= small | maxDets=100 ] = -1.000
Average Recall
                   (AR) @[ IoU=0.50:0.95 | area=medium | maxDets=100 ] = 0.324
                   (AR) @[ IOU=0.50:0.95 | area= large | maxDets=100 ] = 0.650
Average Recall
[05/18 18:53:10 d2.evaluation.coco_evaluation]: Evaluation results for bbox:
                   AP75
                            APs
|:----:|:----:|:----:|:----:|
 41.078 | 58.032 | 43.691 | nan | 25.302 | 41.558 |
[05/18 18:53:10 d2.evaluation.coco evaluation]: Some metrics cannot be computed and is shown as NaN.
[05/18 18:53:10 d2.evaluation.coco_evaluation]: Per-category bbox AP:
 category
                      category
                                           category
 :-----|:----|:-----|:-----|:-----|
 leakage
                      crack
                                   44.277 | leak
                                                        57.518
              nan
 no leak
             14.504
                      water
                                   48.013
```

2nd test of Retinanet model



```
cfg_tuned = get_cfg()
cfg_tuned.merge_from_file(model_zoo.get_config_file("COCO-Detection/faster_rcnn_R_50_FPN_3x.yaml"))
cfg_tuned.DATASETS.TRAIN = ("leak_dataset_train",)
cfg_tuned.DATASETS.TEST = ("leak_dataset_val",)
cfg tuned.DATALOADER.NUM WORKERS = 2 # Increased number of workers
cfg_tuned.MODEL.WEIGHTS = model_zoo.get_checkpoint_url("COCO-Detection/faster_rchn_R_50_FPN_3x.yaml")
cfg_tuned.SOLVER.IMS_PER_BATCH = 4 # Increased batch size
cfg tuned.SOLVER.BASE LR = 0.00125 # Increased learning rate
cfg_tuned.SOLVER.MAX_ITER = 5000 # Increased iterations
cfg_tuned.SOLVER.STEPS = (4000, 4500) # Add learning rate decay steps
cfg.SOLVER.OPTIMIZER = "ADAMW"
cfg.TEST.EVAL_PERIOD = 500
cfg.SOLVER.WEIGHT_DECAY = 0.0005
cfg_tuned.SOLVER.GAMMA = 0.1 # Learning rate decay factor
cfg_tuned.MODEL.ROI_HEADS.BATCH_SIZE_PER_IMAGE = 128 # Increased RoIHead batch size
cfg_tuned.MODEL.ROI_HEADS.NUM_CLASSES = num_classes_from_dataset
os.makedirs(cfg_tuned.OUTPUT_DIR, exist_ok=True)
trainer_tuned = DefaultTrainer(cfg_tuned)
trainer_tuned.resume_or_load(resume=False)
trainer_tuned.train()
```






2nd test of Retinanet model

```
Average Precision (AP) @[ IoU=0.50:0.95 |
                                                      | maxDets=100 ] = 0.499
                                          area=
                                                 all
                                                     | maxDets=100 | = 0.695
Average Precision (AP) @[ IoU=0.50
                                                 a11
                                          area=
Average Precision (AP) @[ IoU=0.75
                                                 all | maxDets=100 ] = 0.547
                                          area=
Average Precision (AP) @[ IoU=0.50:0.95 | area= small | maxDets=100 ] = -1.000
Average Precision (AP) @[ IoU=0.50:0.95 | area=medium | maxDets=100 ] = 0.210
Average Precision (AP) @[ IoU=0.50:0.95 | area= large | maxDets=100 ] = 0.522
Average Recall
                   (AR) @[ IoU=0.50:0.95 | area=
                                                 all | maxDets= 1 ] = 0.608
                                                       maxDets= 10 ] = 0.664
Average Recall
                   (AR) @[ IoU=0.50:0.95 |
                                          area=
                                                 all
Average Recall
                   (AR) @[ IoU=0.50:0.95 | area=
                                                 all
                                                     | maxDets=100 ] = 0.680
                   (AR) @[ IoU=0.50:0.95 | area= small | maxDets=100 ] = -1.000
Average Recall
Average Recall
                   (AR) @[ IoU=0.50:0.95 | area=medium | maxDets=100 ] = 0.347
                   (AR) @[ IoU=0.50:0.95 | area= large | maxDets=100 ] = 0.698
Average Recall
[05/18 20:36:21 d2.evaluation.coco_evaluation]: Evaluation results for bbox:
                   AP75
                        | APS | APm
|:----:|:----:|:----:|:----:|
49.855 | 69.490 | 54.737 | nan | 20.981 | 52.226 |
[05/18 20:36:21 d2.evaluation.coco_evaluation]: Some metrics cannot be computed and is shown as NaN.
[05/18 20:36:21 d2.evaluation.coco_evaluation]: Per-category bbox AP:
 category
                      category
                                            category
 leakage
                      crack
                                   51.123 | leak
                                                        65.168
             nan
 no leak
            | 30.524 | water
                                   52.604
```

Conclusion and Recommendation




Which is the best model?

- Highest Detection Accuracy Achieved an mAP50 of 85.9%, outperforming Detectron2 and RetinaNet.
- Fast and Real-Time Optimized for low-latency inference, ideal for smart water metering systems.
- Strong Recall on Leaks Detected nearly 90% of actual leaks, ensuring critical issues aren't missed.
- Robust Generalization Handled diverse image conditions thanks to built-in data augmentations.
- Stable and Efficient Training Smooth convergence without overfitting, simplifying deployment.

ultralyti Yolon


ESTM Forecasting True Values Predicted Values Predicted Values 10 4 2 0 250 500 750 Time


LSTM





LSTM







Forecast Behavior: Produces smooth and stable forecasts with clear periodic patterns. Strengths: Good at capturing long-term dependencies and seasonality.


Limitations: May underrepresent short-term fluctuations or sudden changes in consumption.


GRU






GRU






GRU (Gated Recurrent Unit)
Forecast Behavior: Similar to
LSTM with stable and consistent
trends, slightly more responsive to
short-term variations.
Strengths: Efficient in training and
performs well with fewer
parameters.
Limitations: Like LSTM, may
smooth out high-frequency noise
or irregularities.


TCN




```
lef residual_block(x, filters, kernel_size, dilation_rate):
    shortcut = x
    x = Conv1D(filters, kernel_size, dilation_rate=dilation_rate, padding='causal')(x)
    x = BatchNormalization()(x)
    x = Activation('relu')(x)
    x = Dropout(0.2)(x)
    x = Conv1D(filters, kernel_size, dilation_rate=dilation_rate, padding='causal')(x)
    x = BatchNormalization()(x)
   if shortcut.shape[-1] != x.shape[-1]:
       shortcut = Conv1D(filters, 1, padding='same')(shortcut)
    x = Add()([shortcut, x])
    return Activation('relu')(x)
inputs = Input(shape=(window_size, 1))
x = residual_block(inputs, 32, 3, 1)
x = residual_block(x, 32, 3, 2)
x = residual_block(x, 32, 3, 4)
x = GlobalAveragePooling1D()(x)
outputs = Dense(1)(x)
model_tcn = Model(inputs, outputs)
model_tcn.compile(optimizer='adam', loss='mse')
model_tcn.fit(X_train, y_train, validation_split=0.1, epochs=50, batch_size=32,
              callbacks=[early_stopping], verbose=1)
```



TCN







TCN (Temporal Convolutional Network)
Forecast Behavior: Forecast is more detailed with visible high-frequency fluctuations.
Strengths: Better at capturing short-term patterns and local variations in consumption.
Limitations: Slightly more complex and potentially more sensitive to noise.

MODELS MATRIX







The LSTM model is better at identifying Normal consumption (887 correct predictions) compared to High consumption (630 correct predictions). It misclassifies 87 instances of Normal as High and 148 instances of High as Normal.

The GRU model shows balanced performance, with slightly fewer correct predictions for Normal (848) than LSTM but better accuracy for High (645). It has fewer misclassifications for High (133) compared to LSTM, suggesting improved sensitivity for detecting High consumption.



The TCN model excels in identifying High consumption (660 correct predictions, the highest among the three models).

However, it has the lowest accuracy for Normal (822) and the highest False High errors (152), indicating it may be more conservative in labeling consumption as High.



Model	MAE↓	MSE↓	RMSE↓	Performance
LSTM	0.92	1.66	1.29	★ Best
GRU	0.94	1.69	1.3	├ Good
TCN	0.99	1.88	1.37	F Worst

